## **Systems Performance Benchmarking**

#### Presented by:

Nicholas A. Caronna, PE Associate & Pharmatech Team Leader CRB Consulting Engineers, Inc. Cary, NC

Laboratories for the 21<sup>st</sup> Century

2003 Annual Conference – Denver, CO

October 23, 2003

## Why Laboratories?

- Laboratories are Energy Intensive
- Consume up to 10x typical office building
- Most existing labs can reduce energy use by 20-30% with existing technology
- Save \$\$ and toxic emissions
- Optimize performance through integrated design and life cycle cost analysis.



## The Engineering Challenge

- Labs must provide safety, typically minimal regard for energy use.
- An Interactive Design Process is required for a functional, sustainable facility.
- There may be Resistance to new ideas.



## **Life Cycle Cost Analysis**

- Life Cycle Cost (LCC) Analysis is a method for selecting the optimum lab facility systems and evaluating options.
- Includes fuel costs, maintenance costs, operating personnel costs.



## **CFD Analysis**

- Computational Fluid Dynamics (CFD) Analysis
  - Helpful to understand airflow characteristics in a lab (or any space).
  - ➤ Critical in Vivarium (Animal) Lab Facilities
  - ➤ Low Velocity Diffusers and Locations
  - ➤ User Impacts on Turbulence



## **Energy Reduction Opportunities**

- Lighting
- HVAC
- Controls
- Building Envelope



## **Energy Reduction Steps**

- Minimize the Load
  - ➤ Reduce Air Volume
  - Analyze Temperature & Humidity Rqmts.
  - ➤ Review Code Rqmts.
  - ➤ Review Eqmt. Plug Loads
  - **≻**Consider Diversity
    - Fume Hoods
    - Climatic Part-loading



## **Energy Reduction Steps**

- Right Sizing Equipment
  - Modular Plant Design (Summer Boiler)
  - > High Efficiency Chillers, Boilers
  - Controls (setbacks)
  - ➤ VAV vs. CAV (save 40-60%)
  - ➤ Variable Speed Drives
  - ➤ Fume Hood Diversity (50% in use)
  - > Small rooms should be sized for 100%
  - ➤ Be skeptical of Eqmt. Loads
- Safety First



### Lab Exhausts

- Reduce Exhaust to lowest, safe level
- Avoid Excess Fume Hoods
- Consider Sash Options
- Review Room Airflow Patterns
- Fume Hood Energy Consumption
  - ▶ 6 ft. hood costs \$4-7/CFM



## Energy Recovery #1 HX Re-Circulated Loop

Pros

Simple Controls


**Minimal Maintenance** 

Ease of Design and Installation

**Cross-contamination is Eliminated** 

Cons

Sensible Energy Recovery Only Relatively Low Efficiency





## **Energy Recovery #2 Heat Pipe**

#### Pros

"Zero" Maintenance

Simplest Design (i.e. minimal controls & motors)


Passive Energy Recovery

**Cross-Contamination is Eliminated** 

#### Cons

Sensible Energy Recovery Only Relatively Low Efficiency







# **Energy Recovery #3 Heat Recovery Wheel**

Pros

Best Efficiency
Recovers Both Latent and Sensible Energy
Cons

Cross-Contamination Possible Limited Life Expectancy (i.e. wheel replacement, 2 to 5 years







# **Energy Recovery #4 Kathabar System**

#### **Pros**

**Good Efficiency** 

Recovers Both Latent and Sensible Energy

Winter-Time Humidification of Air

#### Cons

Relatively Complex (i.e. pumps, controls, piping)


Fluid is Corrosive

High Airside Pressure Drop

Fluid Contacts Both Supply & Exhaust Air Directly

Large Footprint (i.e. larger mech. space)

**Expensive First Cost** 





### **Annual HVAC Energy Operating Costs**

Case Study Using Phoenix Usage Based Controls System Zone Presence Sensor

CV/RH System (13,000 cfm)	\$49,900
VAV/RH System (5,200 cfm; ~40%)	\$29,126
Actual VAV/RH with UBC (2,500 cfm avg.)	\$19,600
UBC Savings Over CAV:	<u>\$30,300</u>

40% of Maximum Flow Was Seen (some hoods @ 20%) 60% Operating Cost Savings Over CAV Seen



## Lighting

- Lighting can represent the largest energy consumer.
- Pursue ambient and dedicated task lighting schemes.
- Use Occupancy/Photosensitive Controls
- Illumination Levels range from 30-100 fc
- Consider indirect/direct lighting



## Lighting

- Consider Compact Fluorescent Lamps
- Occupancy Sensors can save 10-50%.
- Carefully Consider Placement in Lab
  - Parabolic Perpendicular to Benches
  - Indirect/Direct Parallel to Benches



## Sustainability

- Building Envelope to Reduce Solar Load
  - Optimize Fenestration
  - Building Orientation
- Harvest Storm Water for Irrigation
- Harvest Gray Water for Irrigation
- Recover HVAC Condensate for Make-up
- Evaluate Sizes of Once-Thru Air Spaces



## Sustainability (Cont'd)

- Lighting Types
  - Natural Daylighting
  - ➤ Occupancy Controls
  - ➤ More Task Lighting
- Materials of Construction
  - ➤ "Green" products, such as hardwood, veneer and plywood from certified, sustainable forests



## Sustainable Lab Design Criteria

	TYPICAL LAB DESIGN	"GREEN" LAB EXPERIENCE
Lab Equipment Heat Dissipation	10-15 W/SF	8 W/SF
Lab Lighting	3 W/SF	1.5 - 2 W/SF
Office Lighting	3 W/SF	0.75 – 1.0 W/SF
<b>Laboratory Power</b>	10-15 W/SF	8 W/SF
Office Power	4 W/SF	2 W/SF
Compressed Air	5 scfm/outlet	1 scfm/outlet
DHW for Lab Sinks	3 gpm	2.25 gpm
DCW for Lab Sinks	3 gpm	2.2.5 gpm

